

CERTINA

Vis de plaque d'appui pour roue de seconde au centre

Bearing plate screw for sweep second wheel

Tornillo de placa de apoyo para rueda de segundero central

Abstützplatten-Schraube für Zentrumsekundenrad

Vite per la placca d'appoggio per ruota dei secondi al centro



5342

Calibre de base
Basic calibre
Calibre de base
Grundkaliber
Calibro di base

Valable pour les calibres
Applicable for the calibres
Válido para los calibres
Verwendbar für die Kaliber
Adoperabile per i calibri

Observations
Remarks
Observaciones
Bemerkungen
Osservazioni

19-45

19-451

23-35

19-25, 19-251, 19-26, 25-35, 25-36, 25-45, 25-451,
28-15, 28-151, 28-16, 28-161, 28-45, 28-451

Vis de plaque de contre-pivot, dessous pour roue d'ancrage

Screw for lower cap jewel with end-piece, for escape wheel

Tornillo de placa de contrapivote, inferior, para rueda de áncora

Decksteinplättchen-Schraube, unten, für Ankerrad

Vite per placca di controperno, inferiore, per ruota d'ancora



5346

230

240, 258 SC, 304, 344, 344 T, 350, 351, 400, 401, 404, 410, 411, 414, 12-10, 13-10, 15-10, 15-14, 17-10, 19-10, 19-14, 23-20

23-35

19-25, 19-251, 19-26