


ADEC QUARTZ Model No. HT5 CAL. No. DC98 INSTRUCTION MANUAL

The power cell is a monitor power cell that has been factory-installed. For this reason it may wear out before the 3 years from the time of purchase are up.


ADC-9804

SPECIFICATION


- **DISPLAY**
- TIME** Hour/Min/Sec, AM/PM 12/24H
- CALENDAR** Day/Date (Month/Date)
- ALARM 1** Hour/Min (AM/PM)
- ALARM 2** Hour/Min, (AM/PM)
- STOPWATCH** (Month/Date)Min, Sec, 1/100 Sec
(Up to 24 hours)
- TIMER** Min/Sec (up to 99 min)
- DUAL TIME** Hour/Min, Sec, AM/PM
- ADDITIONAL FUNCTION** El internal illumination function
- **BATT. LIFE** About 3 years (CR2016x1)




1 HOW TO SET TIME AND CALENDAR




2 ALARM SETTING (1 & 2)



3 STOPWATCH



4 TIMER



6 CHIME

