

PARTS LIST

CAL. V230B

Cal. V230B (Jewels: 1j)	
PARTS NO.	PARTS NAME
125 231	Train wheel bridge
197 231	Winding stem cock
238 231	Guide pipe for winding stem
261 231	Minute wheel
* 270 231	Center minute wheel
* 270 232	Center minute wheel
* 271 231	Hour wheel
* 271 232	Hour wheel
281 231	Setting wheel
* 354 230	Winding stem (φ80)
* 354 231	Winding stem (φ90)
387 231	Minute wheel bridge
491 122	Dial washer
493 130	Hour wheel ring (Thickness 0.03 mm)
493 131	Hour wheel ring (Thickness 0.05 mm)
493 132	Hour wheel ring (Thickness 0.07 mm)
701 231	Fifth wheel
736 231	Winding stem holder
4000 231	Circuit block
4146 231	Step rotor
4225 230	Battery clamp
4239 231	Rotor stator
4271 026	Battery connection ⊕
4408 232	Dial spacer
4455 231	Reset lever
011 334	Upper hole jewel for step rotor
012 010	Battery clamp screw
012 495	Train wheel bridge screw
012 496	Circuit block screw
012 818	Screw for battery connection ⊕ A
012 819	Screw for battery connection ⊕ B
017 591	Reset pin
017 662	Tube for train wheel bridge A
017 663	Tube for train wheel bridge B
017 664	Tube for train wheel bridge C
SEIZAIKEN TR521SW	Battery

Remarks:

- * Center minute wheel, Hour wheel

There are two different types as specified below.

Combination:

Type	Center minute wheel	Hour wheel
a	270 231	271 231
b	270 232	271 232

- * Winding stem

The type of winding stem panel is determined based on the design of case.