



* Use the movement holder No. B74 for disassembly and assembly.

B740/741 Movement Diagram
 Page 2



