

GRADE	ARBORS					ARM VIBRATING	BALANCE	BALANCE COMPLETE	HAND DUST	BAR SETTING	BARREL	BARREL HUB & SCREW	BUSHINGS		CAMS
	BARREL	PALLET	SETTING	SWEEP SECOND	WINDING								BARREL ARBOR	CENTER STAFF	SETTING
121	X206	X224				1306 □1307	X249-G.	4101			X291				
122	X206	X224				1306 §1307	X249-G.	4096			X291				
123	X190	X5				X172	X236	4047	X257		X265				X174
124	X190	X5				X172	X236	4047	X258		X269				X174
125	X190	X5				X55	X236	4047	X253	X45	X265				X46
126	X190	X5				X55	X236	4047	X254	X45	X269				X46
127	X200	X215				X133	X242	4085			X277				X123
128	X200	X215				X233	X242	4085			X277				
129	X207	X227				X235	X250	4109			X292				
130	X207	X227				X235	X250	4109 -4103			X293				
131	X207	X226				X235	X250-G.	4102			X293				
132	X206	X225				1307	X249	4101			X290				
133	X206	X225				1307	X249	4101 > 4098			X291				
134	X206	X224				1307	X249-G.	4096			X291				
135	X200	X215				X133	X242	4085 < 4073			X275				X123
136	X200	X215				X133	X242	4085			X277				X123
137	X200	X214				X133	X242	4070			X275				X123
138	X200	X215				X233	X242	4085			X275				
139	X200	X215				X233	X242	4085			X277				
140	X200	X214				X233	X242	4070			X275				
141	X190	X208				X55 *1777	X236	4067	X253 ‡2117	X45	X265				X46
142	X190	X208				X55	X236	4067	X252	X45	X269				X46
143	X190	X5				X55	X236	4047	X253	X45	X265				X46
144	X190	X5				X55 *1777	X236	4047	X254 ‡2131	X45	X269				X46
145	X190	X208				X172	X236	4067	X257 *2142		X265				X174
146	X190	X208				X172	X236	4067	X257		X269				X174
147	X190	X5				X172	X236	4047	X257		X265				X174
148	X190	X5				X172	X236	4047	X258 *2141		X269				X174
149	X189	1303				X35	X236-G.	4046 ‡4059	X254 ‡2131		X267				X42
150	X189	1303				X172	X236-G.	4046	X258 *2141		X267				X174
151	1301	2309				1305 □□1773	X242	4073	1539		X275				1313
152	1301	X215				1305 ●●1773	X242	4073	1308		X275				1313
153	1301	X214				1305 ▼▼1773	X242	4070	1308		X277				1313
154	1301	X214				1305 ‡‡1773	X242	4070	1308		X277				1313
155	1301	X214				1305 ●●1773	X242-G.	4069	1308		X277				1313
156	1301	1304				1305 ●●1773	X242-G.	4075 **4076	1308 ‡‡2553		X277				1313
157	1301	2309				1305 ●●1773	X242	4073	1539		X275				1313
158	1301	X215				1305 ‡‡1773	X242	4073	1308		X275				1313
159	1301	X214				1305 ●●1773	X242	4070	1308		X277				1313
160	1301	X214				1305 §§1773	X242	4070	1308		X277				1313

□1307 began with Serial Number 5196001.
 §1307 began with Serial Number 4647501.
 *1777 began with Serial Number 7616001.
 ‡2131 began with Serial Number 7677001.
 *2142 began with Serial Number 7524001.
 ‡2141 began with Serial Number 8177001.
 ‡4059 began with Serial Number 10422401.

‡2131 began with Serial Number 8489001.
 *2141 began with Serial Number 7875001.
 -4103 Breguet Hair Spring began with Serial Number 6757001.
 >4098 Breguet Hair Spring began with Serial Number 6749001.
 *1777 began with Serial Number 7044001.
 ‡2117 began with Serial Number 7768001.
 **4076 began with Serial Number 10249001.
 ‡‡2553 began with Serial Number 13504001.
 <4073 Breguet Hair Spring began with Serial Number 7551001.
 □□1773 began with Serial Number 6972001.

●●1773 began with Serial Number 6992001.
 ▼▼1773 began with Serial Number 7231001.
 ‡‡1773 began with Serial Number 6993001.
 ‡‡1773 began with Serial Number 6994001.
 ●●1773 began with Serial Number 6995001.
 ‡‡1773 began with Serial Number 7576001.
 ‡‡1773 began with Serial Number 7256001.
 ●●1773 began with Serial Number 7257001.
 §§1773 began with Serial Number 7336001.

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

CAMS		CAPS		CLAMPS							CLICK	CLICK FINISH	CLUTCHES		GRADE
SETTING SPRING	ARBOR	RATCHET	BALANCE CAP UPPER	BALANCE CAP LOWER	CASE	MINUTE WHEEL	RATCHET	RATCHET WHEEL	RATCHET WHEEL FINISH	SETTING WHEEL			SETTING	WIND AND SETTING	
											X98			121	
											X98			122	
											X337			123	
											X337			124	
											X338			125	
											X338			126	
										X124	X337			127	
											X337			128	
											X350			129	
											X350			130	
											X349			131	
											X143			132	
											X143			133	
											X98			134	
										X124	X337			135	
										X124	X337			136	
										X124	X338			137	
											X337			138	
											X337			139	
											X338			140	
											X337			141	
											X338			142	
											X337			143	
											2356			144	
											X337			145	
											X338			146	
											X337			147	
											X337 2356			148	
											X24 1800	X25		149	
											X338 1799			150	
1314						1312					1316	E	1807	151	
1314						1315					1316 *1802	E E	1807	152	
1314						1315					1316 1802	E E	1807	153	
1314						1315					1316 1802	C C	1807	154	
1314						1315					1316 1802	C C	1807	155	
1314						1315					1316 *1802	E-1 E-1	1807	156	
1314						1312					1316	E	1807	157	
1314						1315					1316 *1802	E E	1807	158	
1314						1315					1316 *1802	E E	1807	159	
1314						1315					1316 1802	C C	1807	160	

*1802 began with Serial Number 8225001.
 †1802 began with Serial Number 8179001.
 ‡1802 began with Serial Number 6993001.
 §1802 began with Serial Number 6737001.
 ¶1802 began with Serial Number 6463201.
 •1802 began with Serial Number 8267001.

◦1802 began with Serial Number 7779001.
 ||1802 began with Serial Number 7336001.
 †2356 began with Serial Number 11097501.
 ‡1800 began with Serial Number 8489001.
 §1799 began with Serial Number 7875001.

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

GRADE	COLLETS		CUPS		DIAL	FORK	HANDS		HUBS		INDEX	JEWELS			
	BARREL ARBOR	HAIR SPRING	ARBOR	CENTER			HOUR AND MINUTE	SECOND	BARREL	BARREL ARBOR		BALANCE			
												HOLE		CAP	
												UPPER	LOWER	UPPER	LOWER
121		X358			6 ^s		6 ^s	6 ^s				X463	X463	2193	X466
122		1318			6 ^s		6 ^s	6 ^s				X463	X463	2193	X466
123		X352			18 ^s	X1	18 ^s	18 ^s			1544	X443	X443	2191	1348
124		X352			18 ^s	X1	18 ^s	18 ^s			X433	X443	X443	2191	1348
125		X352			18 ^s	X1	18 ^s	18 ^s			1544	X443	X443	2191	1348
126		X352			18 ^s	X1	18 ^s	18 ^s			X433	X443	X443	2191	1348
127		X358			16 ^s		16 ^s	16 ^s				X447	X447	2192	1350
128		X358			16 ^s		16 ^s	16 ^s				X447	X447	2192	1350
129		1330			0 ^s 1st		0 ^s	0 ^s				X455	X455	2194	1356
130		1330-F. X359-B.			0 ^s 1st		0 ^s	0 ^s				X455	X455	2194	1356
131		X359			0 ^s 1st		0 ^s	0 ^s				X455	X455	2194	1356
132		X358			6 ^s		6 ^s	6 ^s				X463	X463	2193	X466
133		X358-F. 1318-B.			6 ^s		6 ^s	6 ^s				X463	X463	2193	X466
134		1318			6 ^s		6 ^s	6 ^s				X463	X463	2193	X466
135		1318-B. X358-F.			16 ^s		16 ^s	16 ^s				X447	X447	2192	1350
136		X358			16 ^s		16 ^s	16 ^s				X447	X447	2192	1350
137		1318			16 ^s	X1	16 ^s	16 ^s				X447	X447	2192	1350
138		X358			16 ^s		16 ^s	16 ^s				X447	X447	2192	1350
139		X358			16 ^s		16 ^s	16 ^s				X447	X447	2192	1350
140		1318			16 ^s	X1	16 ^s	16 ^s				X447	X447	2192	1350
141		X353			18 ^s	X1	18 ^s	18 ^s			X435	X443	X443	2191	1348
142		X353			18 ^s	X1	18 ^s	18 ^s			X435 *X433	X443	X443	2191	1348
143		X352			18 ^s	X1	18 ^s	18 ^s			X433	X443	X443	2191	1348
144		X352			18 ^s	X1	18 ^s	18 ^s			1544	X443	X443	2191	1348
145		X353			18 ^s	X1	18 ^s	18 ^s			X435	X443	X443	2191	1348
146		X353			18 ^s	X1	18 ^s	18 ^s			X435 †X433	X443	X443	2191	1348
147		X352			18 ^s	X1	18 ^s	18 ^s			X433	X443	X443	2191	1348
148		X352			18 ^s	X1	18 ^s	18 ^s			1544	X443	X443	2191	1348
149		X352			18 ^s	X1 ‡1814	18 ^s	18 ^s			X432	2578	2578	1347	1348
150	X351	X352			18 ^s	X1	18 ^s	18 ^s			X432	X443	X443	1347	1348
151		1318			16 ^s		16 ^s	16 ^s				X447	X447	2192	1350
152		1318			16 ^s		16 ^s	16 ^s			1331	X447	X447	2192	1350
153		1318			16 ^s	X1	16 ^s	16 ^s			1331	X447	X447	2192	1350
154		1318			16 ^s	X1	16 ^s	16 ^s			1331	X447	X447	2192	1350
155		1318			16 ^s	X1	16 ^s	16 ^s			1331	X447	X447	2192	1350
156		1318			16 ^s	X1 ‡1814	16 ^s	16 ^s			4356	2580	2580	1351	1350
157		1318			16 ^s		16 ^s	16 ^s				X447	X447	2192	1350
158		1318			16 ^s		16 ^s	16 ^s			1331	X447	X447	2192	1350
159		1318			16 ^s	X1	16 ^s	16 ^s			1331	X447	X447	2192	1350
160		1318			16 ^s	X1	16 ^s	16 ^s			1331	X447	X447	2192	1350

F. = Flat Hair Spring.
 B. = Breguet Hair Spring.
 ‡1814 began with Serial Number 10249901.
 *X433 began with Serial Number 6191501.
 †X433 began with Serial Number 6199101.
 ‡1814 began with Serial Number 10422401.

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

JEWELS														GRADE	
BARREL ARBOR		SWEEP SECOND ARBOR	CENTER		ESCAPE				FOURTH		PALLET				
UPPER	LOWER		UPPER	LOWER	HOLE		CAP		UPPER	LOWER	HOLE		CAP		
					UPPER	LOWER	UPPER	LOWER			UPPER	LOWER	UPPER		LOWER
					1374	X491			1396	X514	1418	2428		121	
			X519	1345	X479	X491			X503	X514	1418	2428		122	
					1365	X481			1387	X505	1410	2247		123	
					1365	X481			1387	X505	1410	2247		124	
					1365	X481			1387	X505	1410	2247		125	
					1365	X481			1387	X505	1410	2247		126	
					1369				1391		1414			127	
					1369				1391		1414			128	
					1378	1384			1400	1406	1419	2254		129	
					1378	1384			1400	1406	1419	2254		130	
					2230	X492			1399	X516	1418	2253		131	
					1375	1383			1397	1405	1418	2426		132	
					1375	1383			1397	1405	1418	2426		133	
					2230	X492			1399	X516	1418	2253		134	
					1368	X486			1390	X510	1414	2426		135	
					1368	X486			1390	X510	1414	2426		136	
					1368	X486			1390	X510	1414	2426		137	
					1368	X486			1390	X510	1414	2426		138	
					1368	X486			1390	X510	1414	2426		139	
					1368	X486			1390	X510	1414	2426		140	
					1365	X481			1387	X505	1410	2247		141	
					1365	X481			1387	X505	1410	2247		142	
			1335	1341	1365	X481			1387	X505	1410	2247		143	
			1335	1341	1365	X481			1387	X505	1410	2247		144	
					1365	X481			1387	X505	1410	2247		145	
					1365	X481			1387	X505	1410	2247		146	
			1335	1341	1365	X481			1387	X505	1410	2247		147	
			1335	1341	1365	X481			1387	X505	1410	2247		148	
			1333	1341	1364	1380	1357	1360	1385	1402	1408	2249	2204	2200	149
			1333	1341	1364	1380	1357	1360	1385	1402	1408	2249	2204	2200	150
															151
					1368	X486			1390	X510	2263	2426			152
			2209	1343	1368	X486			1390	X510	2263	2426			153
			2209	1343	1368	X486			1390	X510	2263	2426			154
			1336	2205	1370	1381			1392	1403	1413	2428			155
			2210	1343	2227	2182	1359	1362	2240	1403	2093	2250	1358	2202	156
															157
					1368	X486			1390	X510	2263	2426			158
			2209	1343	1368	X486			1390	X510	2263	2426			159
			2209	1343	1368	X486			1390	X510	2263	2426			160

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

GRADE	JEWELS				LEVERS				NUTS					PALLETS	
	THIRD		★ ROLLER JEWEL	PALLETT STONE	CAM	CLUTCH	REGU- LATOR ADJUST- ING	SETTING	CENTER		MEAN TIME	REGU- LATOR	REGULA- TOR NUT AND SCREW	WITH STONES	AND FORK WITH STONES
	UPPER	LOWER							PINION	WHEEL					
121	X530	1436	X570	X556-G.			1444 □1445								2589
122	X531	1436	X570	X556-G.			1444 §§1445								2589
123	1422	X533	X559	X546-G.			X171				X579	X584	X2		X596
124	1422	X533	X559	X546-G.			X171				X579	X584	X2		X596
125	1422	X533	X559	X546-G.			X48				X579	X584	X2		X596
126	1422	X533	X559	X546-G.			X48				X579	X584	X2		X596
127	1426		X559	X546-G.			X125								X603
128	1426		X559	X546-G.			X573								X603
129	1433	1439	X571	X558-G.			X575								2975
130	1433	1439	X571	X558-G.			X575								2975
131	1432	X544	X571	X558-G.			X575								2975
132	1425	X538	X570	X556-G.			1445								2589
133	1425	X538	X570	X556-G.			1445								2589
134	1432	X544	X570	X556-G.			1445								2589
135	1425	X538	X559	X546-G.			X125								X603
136	1425	X538	X559	X546-G.			X125								X603
137	1425	X538	X559	X546-G.			X125							X2	X596
138	1425	X538	X559	X546-G.			X573								X603
139	1425	X538	X559	X546-G.			X573								X603
140	1425	X538	X559	X546-G.			X573						X2		X596
141	1422	X533	X559	X546-G.			X48						X2		X596
142	1422	X533	X559	X546-G.			X48				X579	**X584	X2		X596
143	1422	X533	X559	X546-G.			X48				X579	X584	X2		X596
144	1422	X533	X559	X546-G.			X48				X579	X584	X2		X596
145	1422	X533	X559	X546-G.			X171						X2		X596
146	1422	X533	X559	X546-G.			X171				X579	†X584	X2		X596
147	1422	X533	X559	X546-G.			X171				X579	X584	X2		X596
148	1422	X533	X559	X546-G.			X171				X579	X584	X2		X596
149	1420	1435	X559 *2075-D.	X546-S.			X43				X579	X584	X2 **2675		X596 **2676
150	1420	1435	X559	X546-G.			X171				X579	X584	X2		X596
151			X559	X546-G.			1440 *1441								2345
152	1425	X538	X559	X546-G.			1440 †1441				1442 †1443	1446	1447		X603
153	1425	X538	X559	X546-G.			1440 ^1441				1442 ^1443	1446	1447	X2	X596
154	1425	X538	X559	X546-G.			1440 †1441				1442 †1443	1446	1447	X2	X596
155	1427	1436	X559	X546-G.			1440 *1441				1442 *1443	1446	1447	X2	X596
156	2276	1436	X559 *2075-D.	X546-S.			1440 *1441				1442 *1443	1446	1447	2675	X596-S. *2676
157			X559	X546-G.			1440 1441				1442 1443				2345
158	1425	X538	X559	X546-G.			1440 *1441				1442 *1443	1446	1447		X603
159	1425	X538	X559	X546-G.			1440 †1441				1442 †1443	1446	1447	X2	X596
160	1425	X538	X559	X546-G.			1440 ^1441				1442 ^1443	1446	1447	X2	X596

On Roller Jewel: D = Double Roller.
 *2075-D. & 2676 began with Serial Number 10249901.
 †1441 & 1443 began with Serial Number 6995001.
 ‡1441 & 1443 began with Serial Number 7579001.
 §1441 & 1443 began with Serial Number 7259001.
 ¶1441 & 1443 began with Serial Number 7257001.

§1441 & 1443 began with Serial Number 7336001.
 *1441 & 1443 began with Serial Number 6972001.
 †1441 & 1443 began with Serial Number 6992001.
 ‡1441 & 1443 began with Serial Number 7231001.
 §1441 & 1443 began with Serial Number 6993001.
 ¶1441 & 1443 began with Serial Number 6994001.
 ¶1445 began with Serial Number 5196001.

§§1445 began with Serial Number 4647501.
 * (2075-D)
 ** 2675 } began with Serial Number 10422401.
 ‡ 2676 }
 **X584 began with Serial Number 6191501.
 ††X584 began with Serial Number 6199101.

*There is considerable variation in the diameter of jewel pins or roller jewels used in the same grade of movements. In filling orders assorted diameters will be supplied.

†Two different forms of Pallets have been used, the difference being the thickness of Jewel or Stone required; those taking thin ones being known as New Style. In filling orders, unless Old Style is mentioned, the New Style will be sent.

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

PALLET	PINIONS											PINS		PIVOT	RATCHET	GRADE
	FORK AND ARBOR WITH STONES	BEVEL	BEVEL SETTING	CANNON	CENTER	ESCAPE	FOURTH	SETTING	SUB CENTER	SWEEP SECOND	THIRD	BEVEL PINION	SETTING	BEVEL PINION		
2731	1353	1458	X670	X684	X695	1463	1465	121	
2731	1353	1458	X670	X684	X695	1463	1465	122	
X615	X178	X180	X652	X672	X182	1876	X179	123	
X615	X178	X180	X652	X672	X182	1876	X179	124	
X615	X49	X50	X652	X672	X7	X6	125	
X615	X49	X50	X652	X672	X7	X6	126	
X622	X126	X127	X660	X677	X659	X700	127	
X622	X638	X646	X660	X677	X691	X703	X710	128	
2986	X641	X650	X671	X685	X696	X708	X711	129	
2986	X641	X650	X671	X685	X696	X708	X711	130	
2986	X641	X650	X671	X685	X696	X708	X711	131	
2731	1353	1458	X670	X684	X695	1463	1465	132	
2731	1353	1458	X670	X684	X695	1463	1465	133	
2761	1353	1458	X670	X684	X695	1463	1465	134	
X622	1454	X127	X660	X677	X659	X700	135	
X622	1454	X127	X660	X677	X659	X700	136	
X621	1454	X127	X660	X677	X688	X700	137	
X622	X638	X646	X660	X677	X691	X703	X710	138	
X622	X638	X646	X660	X677	X691	X703	X710	139	
X621	X638	X646	X660	X677	X691	X703	X710	140	
X615	1849	X50	X652	X672	X7	X6	141	
X615	X49	X50	X652	X672	X7	X6	142	
X615	X49	X50	X652	X672	X7	X6	143	
X615	1849	X50	X652	X672	X7	X6	144	
X615	X178	X180	X652	X672	X182	1876	X179	145	
X615	X178	X180	X652	X672	X182	1876	X179	146	
X615	X178	X180	X652	X672	X182	1876	X179	147	
X615	X178	X180	X652	X672	X182	1876	X179	148	
1449 *2573	1849	X28	X652	1459	X7	X6	149	
1449	X178	X180	X652	1459	X182	1876	X179	150	
X622	1455 *1851	1457	X660	1461	X659	X700	1464	151	
X622	1455 †1851	1457	X660	1461	X659	X700	1464	152	
X621	1455 *1851	1457	X660	1461	X659	X700	1464	153	
X621	1455 ‡1851	1457	X660	1461	X659	X700	1464	154	
X621	1455 *1851	1457	X660	1461	X659	X700	1464	155	
1450 *2593	1455 ‡1851	1457	X660	1462	X659	X700	1464	156	
X622	1455 ‡1851	1457	X660	1461	X691	X703	1464	157	
X622	1455 ‡1851	1457	X660	1461	X691	X703	1464	158	
X621	1455 *1851	1457	X660	1461	X691	X703	1464	159	
X621	1455 ‡1851	1457	X660	1461	X691	X703	1464	160	

*2593 began with Serial Number 10249901.
 †2573 began with Serial Number 10422401.
 ‡1851 began with Serial Number 6972001.
 †1851 began with Serial Number 6992001.
 *1851 began with Serial Number 7231001.
 ‡1851 began with Serial Number 6993001.

*1851 began with Serial Number 6994001.
 ‡1851 began with Serial Number 6995001.
 †1851 began with Serial Number 7576001.
 ‡1851 began with Serial Number 7256001.
 †1851 began with Serial Number 7257001.
 ‡1851 began with Serial Number 7336001.

Two different forms of Pallets have been used, the difference being the thickness of Jewel or Stone required; those taking thin ones being known as New Style. In filling orders, unless Old Style is mentioned, the New Style will be sent.

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

GRADE	RING FRICTION	REGULATOR	★ROLLERS					SCREWS							
			COMBINATION		SAFETY	TABLE		ARM VIBRATING	BALANCE	BANKING	BAR SETTING	BRIDGE			
			WITHOUT PIN	WITH PIN		WITHOUT PIN	WITH PIN					ARBOR SWEEP SECOND	BARREL	BEVEL PINION	CENTER
121		X743				X759	2432		1570	1577			935		
122		X742				X759	2432		1570	1577			935		
123		X720				X749	2068		888	890			893		
124		X720				X749	2068		888	890			893		
125		X720				X749	2068		888	890	907				
126		X720				X749	2068		888	890	907				
127		X732				X749	2068		1568	1575			1585		
128		X739				X749	2068		1568	1575			1585		
129		X748				X761	2433		1574	1578			899		
130		X748-F. X746-B.				X761	2433		1574	1578			899		
131		X746				X761	2433		1571	1578			899		
132		X745				X759	2432		1569	1577			935		
133		X745-F. X742-B.				X759	2432		1569	1577			935		
134		X742				X759	2432		1570	1577			935		
135		1468-B. X732-F.				X749	2068		1568	1575			1585		
136		X732				X749	2068		1568	1575			1585		
137		X736				X749	2068		1568	1575			1585		
138		X739				X749	2068		1568	1575					
139		X739				X749	2068		1568	1575					
140		X738				X749	2068		1568	1575					
141		X722				X749	2068		888	890	907				
142		X722 *X721				X749	2068		888	890	907				
143		X720				X749	2068		888	890	907				
144		X720				X749	2068		888	890	907				
145		X722				X749	2068		888	890			893		
146		X722 †X721				X749	2068		888	890			893		
147		X720				X749	2068		888	890			893		
148		X720				X749	2068		888	890			893		
149	X31	X720			†1888	X749 *1884	2068 *2382	885	886	889	901				
150		X720				X749	2068		886	889			893		
151		1467				X749	2068		1568	1575			1584		
152		1467				X749	2068		1568	1575			1584		
153		X729				X749	2068		1568	1575			1584		
154		X729				X749	2068		1568	1575			1584		
155		X729				X749	2068		886	1575			1584		
156		1469			†1888	X749 †1884	2068-S. †2382		886	890	902		1584		
157		1467				X749	2068		1568	1575			1584		
158		1467				X749	2068		1568	1575			1584		
159		X729				X749	2068		1568	1575			1584		
160		X729				X749	2068		1568	1575			1584		

F. - Flat Hair Spring.
 B. - Breguet Hair Spring.
 †⁽¹⁸⁸⁸⁾₍₂₃₈₂₎ began with Serial Number 10249001.

*X721 began with Serial Number 6191501.
 †X721 began with Serial Number 6199101.
 †⁽¹⁸⁸⁸⁾₍₂₃₈₂₎ began with Serial Number 10422401.

★There is considerable variation in the diameter of jewel pins or roller jewels used in the same grade of movements. In filling orders assorted diameters will be supplied.

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

SCREWS

PALLET	BRIDGE		CAM SETTING	CAM SETTING SPRING	CAP ARBOR	CAP BRIDGE	CAP RATCHET	CASE	CLAMP				RATCHET	GRADE
	WINDING								BALANCE JEWEL	CASE	MINUTE WHEEL	PALLET JEWEL		
	LONG	SHORT												
1587								1594						121
1587								1594						122
			898					903						123
			898					903						124
	896	897	916					899	903					125
	896	897	916					899	903					126
1586								1590						127
1586								1590						128
1588								1595						129
1588								1595						130
1588								1595						131
1587								1594						132
1587								1594						133
1587								1594						134
1586								1590						135
1586								1590						136
1586								1590						137
1586								1590						138
1586								1590						139
1586								1590						140
	896	897						899	903					141
	896	897						899	903					142
	896	897						899	903					143
	896	897						899	903					144
			898					903						145
			898					903						146
			898					903						147
			898					903						148
	896	897	916					899	901-L. 902-S.	903				149
			898						903					150
894				1599					1591			926		151
894				1599					1591			926		152
894				1599					1591			926		153
894				1599					1591			926		154
894				1599					1591			926		155
894				2289					1591			926		156
894				1599					1591			926		157
894				1599					1591			926		158
894				1599					1591			926		159
894				1599					1591			926		160

L. = Long.
S. = Short.

GRADE	SCREWS														
	CLAMP		CLICK	CLUTCH SETTING	CUP ARBOR	COCK		DIAL	DIAL FOOT	HUB BARREL	INDEX	JEWEL			
	RATCHET WHEEL	SETTING WHEEL				BALANCE						BARREL LOWER	CENTER		
						UPPER	LOWER						UPPER	UPPER	
121					<i>986</i>			1600				1604	1604		
122					<i>985</i>			1600				1604	1604		
123					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		
124					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		
125					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		
126					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		
127		910			1596			<i>2438</i>				<i>913</i>	<i>913</i>		
128					<i>1585</i>			<i>2438</i>				<i>913</i>	<i>913</i>		
129					<i>899</i>			<i>2440</i>				<i>2020</i>	<i>2020</i>		
130					<i>899</i>			<i>2440</i>				<i>2020</i>	<i>2020</i>		
131					<i>899</i>			<i>2440</i>				<i>2020</i>	<i>2020</i>		
132					<i>935</i>			1600				1604	1604		
133					<i>935</i>			1600				1604	1604		
134					<i>935</i>			1600				1604	1604		
135		910			1596			<i>2438</i>				<i>913</i>	<i>913</i>		
136		910			1596			<i>2438</i>				<i>913</i>	<i>913</i>		
137		910			1596			<i>2438</i>				<i>913</i>	<i>913</i>		
138					<i>1585</i>			<i>2438</i>				<i>913</i>	<i>913</i>		
139					<i>1585</i>			<i>2438</i>				<i>913</i>	<i>913</i>		
140					<i>1585</i>			<i>2438</i>				<i>913</i>	<i>913</i>		
141					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		
142					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		
143					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		<i>914</i>
144					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		<i>913</i>
145					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		
146					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		
147					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		<i>913</i>
148					<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		<i>913</i>
149				907	<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		<i>913</i>
150			1722		<i>908</i>			<i>911</i>		<i>912</i>		<i>913</i>	<i>913</i>		<i>913</i>
151			1601		<i>1584</i>			<i>2438</i>				<i>913</i>	<i>913</i>		
152			1601		<i>1584</i>			<i>2438</i>		1603		<i>913</i>	<i>913</i>		
153			1601		<i>1584</i>			<i>2438</i>		1603		<i>913</i>	<i>913</i>		1600
154			1601		<i>1584</i>			<i>2438</i>		1603		<i>913</i>	<i>913</i>		1606
155			2292		<i>1584</i>			<i>2438</i>		1603		<i>913</i>	<i>913</i>		1606
156			2292		<i>1584</i>			<i>2438</i>		1603		2293	<i>913</i>		
157			1601		<i>1584</i>			<i>2438</i>				<i>913</i>	<i>913</i>		
158			1601		<i>1584</i>			<i>2438</i>		1603		<i>913</i>	<i>913</i>		
159			1601		<i>1584</i>			<i>2438</i>		1603		<i>913</i>	<i>913</i>		1606
160			1601		<i>1584</i>			<i>2438</i>		1603		<i>913</i>	<i>913</i>		1606

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

SCREWS

JEWEL											LEVER				GRADE
CENTER	ESCAPE		FOURTH		PALLET				THIRD		CAM	CLUTCH	SETTING	REGULA-TOR ADJUST-ING	
LOWER	UPPER	LOWER	UPPER	LOWER	UPPER	LOWER	CLAMP		UPPER	LOWER					
							UPPER	LOWER							
	1604		1604						1604				1609	121	
1607													1609	122	
	914		914		914				914				1608	123	
	914		914		914				914				1608	124	
	914		914		914				914				916	125	
	914		914		914				914				916	126	
														127	
														128	
	2020		2020						2020				1609	129	
	2020		2020						2020				1609	130	
	2020		2020						2020				1609	131	
	1604		1604						1604				1609	132	
	1604		1604						1604				1609	133	
	1604		1604						1604				1609	134	
	913		913						913					135	
	913		913						913					136	
	913		913						913					137	
	913		913						913					138	
	913		913						913					139	
	913		913						913					140	
	914		914		914				914				916	141	
	914		914		914				914				916	142	
	914		914		914				914				916	143	
	913		913		913				913				916	144	
	914		914		914				914				1608	145	
	914		914		914				914				1608	146	
	913		913		913				913				1608	147	
	913		913		913				913				1608	148	
	913	1606	913	1606	913	1606			913	1606			916	149	
	913	1606	913	1606	913	1606			913	1606			1608	150	
												1601 *1996	1601	151	
	913		913						913			1601 †1996	1601	152	
913	913		913						913			1601 ‡1996	1601	153	
913	913		913						913			1601 §1996	1601	154	
913	913		913						913			1601 °1996	1601	155	
913	1994	1606		2959		1606	1994			1606		1601 *1996	1601	156	
												1601 □1996	1601	157	
	913		913						913			1601 1996	1601	158	
913	913		913						913			1601 •1996	1601	159	
913	913		913						913			1601 §1996	1601	160	

*1996 began with Serial Number 6972001.
 †1996 began with Serial Number 6992001.
 ‡1996 began with Serial Number 7231001.
 §1996 began with Serial Number 6993001.
 °1996 began with Serial Number 6994001.

*1996 began with Serial Number 6995001.
 °1996 began with Serial Number 7576001.
 ||1996 began with Serial Number 7256001.
 •1996 began with Serial Number 7257001.
 §1996 began with Serial Number 7336001.

GRADE	SCREWS													
	MAIN	MAIN WHEEL SEAT	MEAN TIME	PILLAR	PINION BEVEL SETTING	PLATE TOP	POTANCE	REGULATOR ADJUSTING	RING EXTENSION	SHIPPER SETTING	SPRING			
										VIBRATING ARM	CAM	CLICK	DRAG	CLUTCH LEVER
121	1611					935					1615		928	
122	1611					935					1615		928	
123	X184			921 *1612			922				913	898	910	
124	X184			921 *1612			922				913	898	910	
125	X54			921			922				925		910	
126	X54			921			922				925		910	
127	X63					1585					925		913	
128	X63					1585					913		913	
129	920					899					926		1617	
130	920					899					926		1617	
131	920					899					926		1617	
132	2295					935					1615		928	
133	2295					935					1615		928	
134	1611					935					1615		928	
135	X63					1585					925		913	
136	X63					1585					925		913	
137	X63					1585		923			925		913	
138	X63					1585					913		913	
139	X63					1585					913		913	
140	X63					1585		923			913		913	
141	X54			921			922				925		910	
142	X54			921			922				925		910	
143	X54			921			922				925		910	
144	X54			921			922				925		910	
145	X63			921 *1612			922				913	898	910	
146	X63			921 *1612			922				913	898	910	
147	X184			921 *1612			922				913	898	910	
148	X184			921 *1612			922				913	898	910	
149	X34			921			922						910	
150	X184			921 *1612			922				913	898	910	
151	1610					1584							1615	1615
152	1610					1584							1615	1615
153	1610					1584							1615	1615
154	1610					1584							1615	1615
155	2291					1584							1615	1615
156	2291					1584							1615	1615
157	1610					1584							1615	1615
158	1610					1584							1615	1615
159	1610					1584							1615	1615
160	1610					1584							1615	1615

*1612 Used under cock.

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

SCREWS											SEAT MAIN WHEEL	SHIPPER SETTING	SLEEVES		GRADE
SPRING			STOP		STUD HAIR SPRING	WHEEL				ARBOR WIND- ING			SUB- CENTER		
REGU- LATOR	SETTING	SETTING LEVER	SETTING CAM	LEVER		INTER- WIND- ING	INTER- SET- TING	MINUTE	RATCHET					SETTING	
	904	904			<i>1620</i>										121
	904	904			<i>1620</i>										122
	928				<i>934</i>										123
	928				<i>934</i>										124
	910	910			<i>934</i>										125
	910	910			<i>934</i>										126
	1617	922			<i>934</i>										127
	898				<i>934</i>	937									128
	926	926			<i>1621</i>										129
	926	926			<i>1621</i>										130
	926	926			<i>1621</i>										131
	904	904			<i>1620</i>										132
	904	904			<i>1620</i>										133
	904	904			<i>1620</i>										134
	1617	922			<i>934</i>										135
	1617	922			<i>934</i>										136
<i>913</i>	1617	922			<i>934</i>										137
	898				<i>934</i>	937									138
	898				<i>934</i>	937									139
<i>913</i>	898				<i>934</i>	937									140
	910	910			<i>934</i>										141
	910	910			<i>934</i>										142
	910	910			<i>934</i>										143
	910	910			<i>934</i>										144
	928				<i>934</i>										145
	928				<i>934</i>										146
	928				<i>934</i>										147
	928				<i>934</i>										148
	910			<i>913</i>	<i>934</i>										149
	928				<i>934</i>										150
	1618				<i>934</i>				<i>1601</i>				1912		151
	1618				<i>934</i>				<i>1601</i>				1912		152
	1618				<i>934</i>				2026				1912		153
	1618				<i>934</i>				2026				1912		154
	1618				<i>934</i>				2292				1912		155
	1618				<i>934</i>				2026				1912		156
	1618				<i>934</i>				<i>1601</i>				1912		157
	1618				<i>934</i>				<i>1601</i>				1912		158
	1618				<i>934</i>				2026				1912		159
	1618				<i>934</i>				2026				1912		160

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

GRADE	SPRINGS											STAFF			STOP
	ARM VIBRATING	CAM	CLICK	HAIR		LEVER		MAIN		REGULATOR	SETTING	★BALANCE	CENTER	SUB-CENTER	WINDING ARBOR SLEEVE
				NUMBER	STR'GTH	CLUTCH	SETTING	NUMBER	STR'GTH						
121	1471		X103	X806	1		1258	X824	.007		1479	868-C.	2360		
122	1471		X103	X805	2		1258	X824	.00675		1479	868-C.	2360		
123	X183	X173	X112	X791	2			X812	.009		X129	857	2357		
124	X183	X173	X112	X791	2			X812	.009		X129	857	2357		
125	X61		X112	X791	2		X53	X812	.009		X52	857	2357		
126	X61		X112	X791	2		X53	X812	.009		X52	857	2357		
127	X131		X128	X797	1		X130	X817	.008		X129	861	2358		
128	X183		X128	X797	1			X817	.008		X830	861	2358		
129	X765		X776	X808	1		X811	X826	.00625		X832	869	2361		
130	X765		X776	X808-F. X807-B.	1 5		X811	X826	.00625		X832	869	2361		
131	X765		X776	X807	2		X811	X826	.00625		X832	869-C.	2361		
132	1471		X103	X806	1		1258	X824	.007		1479	868	2360		
133	1471		X103	X805-B. X806-F.	2 1		1258	X824	.007		1479	868	2360		
134	1471		X103	X805	2		1258	X824	.007		1479	868-C.	2360		
135	X131		X128	X796-B. X797-F.	2 1		X130	X817	.008		X129	861	2358		
136	X131		X128	X797	1		X130	X817	.008		X129	861	2358		
137	X131		X128	X796	3		X130	X817	.008	X826	X129	861	2358		
138	X183		X128	X797	1			X817	.008		X830	861	2358		
139	X183		X128	X797	1			X817	.008		X830	861	2358		
140	X183		X128	X796	3			X817	.008	X826	X830	861	2358		
141	X61		X112	X792	1		X53	X812	.009		X51	857	2357		
142	X61		X112	X792	1		X53	X812	.009		X51	857	2357		
143	X61		X112	X791	2		X53	X812	.00875		X51	857-C.	2357		
144	X61		2355	X791	2		X53	X812	.00875		X51	857-C.	2357		
145	X183	X173	X112	X792	1			X812	.009		X129	857	2357		
146	X183	X173	X112	X792	1			X812	.009		X129	857	2357		
147	X183	X173	X112	X791	2			X812	.00875		X129	857-C.	2357		
148	X183	X173	X112 *2355	X791	2			X812	.00875		X129	857-C.	2357		
149			X112 †1895	X791 ‡2692	1 1			X812	.0085		X44	857-C. ‡2516-C.	2357		
150	X183	X173	X112 †1895	X791	2			X812	.0085		X129	857-C.	2357		
151			1472	X796	3	1476		X817	.008		1477 1478	861	1482		
152			1472 ■ 1896	X796	4	1476		X817	.008		1477 ● 1478	861	1482		
153			1472 ** 1896	X796	4	1476		X817	.00775		1477 □□ 1478	861-C.	1482		
154			1472 § 1896	X796	4	1476		X817	.00775		1477 § 1478	861-C.	1482		
155			1472 †† 1896	X796	2	1476		X817	.00775		1477 ** 1478	861-C.	1482		
156			1472 †† 1896	X796	2	1476		X817	.0075		1477 ††† 1478	861-C. *2532-C.	1482		
157			1472	X796	3	1476		X817	.008		1477 ■ 1478	861	1482		
158			1472 1896	X796	4	1476		X817	.008		1477 ● 1478	861	1482		
159			1472 ‡ 1896	X796	4	1476		X817	.00775		1477 ▲ 1478	861-C.	1482		
160			1472 > 1896	X796	3	1476		X817	.00775		1477 > 1478	861-C.	1482		

F. = Flat Hair Spring.
 B. = Breguet Hair Spring.
 ⊙ Breguet Hair Spring with Serial Number 7551001.
 ⊕ Breguet Hair Spring with Serial Number 6757001.
 ⊖ Breguet Hair Spring with Serial Number 6749001.
 *2532-C. began with Serial Number 10249901.
 ‡ (2692
 ‡ 2516-C.) began with Serial Number 10422401.
 †2355 began with Serial Number 11148501.
 †1895 began with Serial Number 8489001.

‡1895 began with Serial Number 7875001.
 †1478 began with Serial Number 6972001.
 †1478 began with Serial Number 6992001.
 †1896 began with Serial Number 8225001.
 □□1478 began with Serial Number 7231001.
 ●1896 began with Serial Number 8179001.
 † (1478) began with Serial Number 6993001.
 **1478 began with Serial Number 6994001.
 ††1896 began with Serial Number 6737001.

††1478 began with Serial Number 6995001.
 ‡‡1896 began with Serial Number 8463201.
 ††1478 began with Serial Number 7576001.
 ●1478 began with Serial Number 7250001.
 ††1896 began with Serial Number 8267001.
 ††1478 began with Serial Number 7257001.
 ††1896 began with Serial Number 7779001.
 > (1478)
 > (1896) began with Serial Number 7336001.

★ See notes on Balance Staffs in Special Information Section.

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

STOP WORKS		STUDS			WASHERS							WHEELS			GRADE
MALE	FEMALE	HAIR SPRING	MAIN WHEEL	MEAN TIME	ARBOR	CENTER FINION	MAIN SCREW	MAIN SCREW FINISH	STAFF CENTER	WHEEL RATCHET	WHEEL RATCHET FINISH	CENTER	CENTER COM- PLETE	★ ESCAPE	
		852					1485					1552-G.	2159-G.	1490	121
		1481					1485					1552-G.	2159-G.	1490	122
		X843					X185					943	2157	981	123
		X843					X185					943	2157	981	124
		X843										943	2157	981	125
		X843										943	2157	981	126
		X849					X134					948	2166	985	127
		X849					X134					948	2166	985	128
		854										956	1714	993	129
		854-F. 853-B.										956	1714	993	130
		853										1928-G.	2160-G.	993-S.	131
		852					X153					955	2167	1490	132
		852-F. 1481-B.					X153					955	2167	1490	133
		1481					1485					1552-G.	2159-G.	1490	134
		1480-B. X849-F.					X134					948	2166	985	135
		X849					X134					948	2166	985	136
		1480					X134					948	2166	985	137
		X849					X134					948	2166	985	138
		X849					X134					948	2166	985	139
		1480					X134					948	2166	985	140
		X844										943	2157	981	141
		X844										943	2157	981	142
		X843							1553			2296	2157	981	143
		X843							1553			2296	2157	981	144
		X844					X134					943	2157	981	145
		X844					X134					943	2157	981	146
		X843					X185		1553			2296	2157	981	147
		X843					X185		1553			2296	2157	981	148
X11	X12	X843							1553			2296	2157	2168	149
X11	X12	X843					X185		1553			2296	2157	2168	150
		1480					1484	E	1554			1567	2158	985	151
		1480					1484	E	1554			2336	2158	985	152
		1480					1484	E	1554	1486	E	2336	2158	985	153
		1480					1484	B	1554	1486	B	1487	2364	985	154
		1480					1484	C	1554			1487	2364	2168	155
		1480					1484	A	1554	1486	A	1487	2364	2168	156
		1480					1484	E	1554			1567	2158	985	157
		1480					1484	E	1554			2336	2158	985	158
		1480					1484	E	1554	1486	E	2336	2158	985	159
		1480					1484	B	1554	1486	B	1487	2364	985	160

F. = Flat Hair Spring.
B. = Breguet Hair Spring.

★ Two diameters of escape wheels have been made in 18, 16 and 6 sizes. The larger being known as New Style (N.S.) which will be supplied unless Old Style (O.S.) is ordered.

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

GRADE	WHEELS														
	★ ESCAPE AND PINION	FIRST	FIRST COM- PLETE	FOURTH	FOURTH AND PINION	HOUR	INTERMEDIATE		MAIN		MINUTE	RATCHET		RING	SETTING
							SETTING	WIND- ING	NUMBER	FINISH		NUMBER	FINISH		
121	1495			2377	2376	1937	1497	X109	<i>X154</i>		1500	<i>X108</i>			1502
122	1495			2377	2376	1937	1497	X109	<i>X154</i>		1500	<i>X108</i>			1502
123	994			1008	1024	X186		X177	<i>X176</i>		X187	1064			X176
124	994			1008	1024	X186		X177	<i>X176</i>		X187	1064			X176
125	994			1008	1022	X59	X58	X38	X56		1062	<i>X39</i>			X57
126	994			1008	1022	X59	X58	X38	X56		1062	<i>X39</i>			X57
127	999			1019	X657	X140	X137	X136	<i>X135</i>		1062	<i>X139</i>			X138
128	999			1019	1030	X140		1047	<i>X135</i>		1062	<i>X139</i>			1071
129	1007			1021	1035	1045		1049	<i>1054</i>		1063	<i>1069</i>			1073
130	1007			1021	1035	1045		1049	<i>1054</i>		1063	<i>1069</i>			1073
131	1007-S.			1021	1035	1045		1049	<i>1054</i>		1063	<i>1069</i>			1073
132	1495			1019	1034	1937	1497	X109	<i>X154</i>		1500	<i>X108</i>			1502
133	1495			1019	1034	1937	1497	X109	<i>X154</i>		1500	<i>X108</i>			1502
134	1495			1019	1034	1937	1497	X109	<i>X154</i>		1500	<i>X108</i>			1502
135	999			1019	X657	X140	X137	X136	<i>X135</i>		1062	<i>X139</i>			X138
136	999			1019	X657	X140	X137	X136	<i>X135</i>		1062	<i>X139</i>			X138
137	999			1019	1027	X140	X137	X136	<i>X135</i>		1062	<i>X139</i>			X138
138	999			1019	1030	X140		1047	<i>X135</i>		1062	<i>X139</i>			1071
139	999			1019	1030	X140		1047	<i>X135</i>		1062	<i>X139</i>			1071
140	999			1019	1030	X140		1047	<i>X135</i>		1062	<i>X139</i>			1071
141	994			1008	1022	X59	X58	X38	X56		1062	1064			X57
142	994			1008	1022	X59	X58	X38	X56		1062	1064			X57
143	994			1008	1022	X59	X58	X38	X56		1062	1064			X57
144	994			1008	1022	X59	X58	X38	X56		1062	1064			X57
145	994			1008	1024	X186		X177	<i>X176</i>		X187	<i>X39</i>			X176
146	994			1008	1024	X186		X177	<i>X176</i>		X187	<i>X39</i>			X176
147	994			1008	1024	X186		X177	<i>X176</i>		X187	1064			X176
148	994			1008	1024	X186		X177	<i>X176</i>		X187	1064			X176
149	2337			1008	1022	X40		X38	X113		1055	<i>X39</i>		X37	
150	2337			1008	1024	X186		X177	<i>X176</i>		X187	1064			X176
151	1493			1019	X657	1496			<i>1498</i>	E-6	1499	<i>1501</i>	E-6		
152	1493			1019	X657	1496			<i>1498</i>	E-5	1499	<i>1501</i>	E-5		
153	1493			1019	X657	1496			<i>1498</i>	E-3	1499	<i>1501</i>	E-3		
154	1493			1019	X657	1496			<i>1498</i>	E-2	1499	<i>1501</i>	E-2		
155	1493-S.			1019	X657	1496			<i>1498</i>	B-2	1499	<i>1501</i>	B-2		
156	1494			1019	X657	1496			<i>1498</i>	A	1499	<i>1501</i>	A		
157	1493			1019	1030	1496			<i>1498</i>	E-6	1499	<i>1501</i>	E-6		
158	1493			1019	1030	1496			<i>1498</i>	E-5	1499	<i>1501</i>	E-5		
159	1493			1019	1030	1496			<i>1498</i>	E-3	1499	<i>1501</i>	E-3		
160	1493			1019	1030	1496			<i>1498</i>	E-2	1499	<i>1501</i>	E-2		

★Two diameters of escape wheels have been made in 18, 16 and 6 sizes. The larger being known as New Style (N.S.) which will be supplied unless Old Style (O.S.) is ordered.

Numbers appearing in italics will be found in the Elgin Genuine Material System and may be ordered by bottle or compartment number.

