


Calibre : 9231 / 1900

Function : Date-day, Sun and Moon

Illustration




A. Set the time - Hour, Minute, Sun & Moon



1. Pull the crown to position 2.
2. Turn the crown clockwise to set the hour / minute hands and Sun and Moon to the desired time.
3. Push the crown back to position 1 .

B. Set the Date




1. Pull the crown to position 2 .
2. Turn the crown clockwise. Continue to turn the crown until the desired date is set.
3. Push the crown back to position 1.

Quick Correction of Date :

1. Set the crown to position 1 .
2. Press the button A step-by-step to advance the date until the desired date is set.

!! Attention 注意 !! : The date advances at 00:00 midnight, not 12:00 noon.

C. Set the Day



1. Pull the crown to position 2 .
2. Turn the crown clockwise to advance the day hand until the desired day is set . The day hand will advance one day when 04:00 in the morning is reached.
3. Push the crown back to position 1 .

Battery : 371 - SR 920 SW