

# PARTS CATALOGUE Cal.2B21A

### Cal.2B21A (1j)






HATTORI SEIKO CO., LTD.



<sup>\* 🖒</sup> Please see remarks on the last page.



#### Remarks:

#### Winding stem

\*354235..... The type of winding stem is determined based on the design of cases and dials.

Check the case number and refer to "SEIKO Quartz Casing Parts Catalogue" to

choose a corresponding winding stem,

012 010	Battery cłamp screw
012 024	Circuit block screw
012 495	Train wheel bridge screw
012 818	Screw for battery connection (+) (A)
012 819	Screw for battery connection (+) (B)

017 591	Reset pin
017 662	Tube for train wheel bridge (A)
017 663	Tube for train wheel bridge (B)
017 664	Tube for train wheel bridge (C)

## TECHNICAL GUIDE



CAL. 2B21A


#### CONTENTS

I.	SPECIFICATIONS	. 1
11.	STRUCTURE OF CIRCUIT BLOCK	. 1
III.	DISASSEMBLING, REASSEMBLING AND LUBRICATING	2
	Hands ~ Hour wheel	. 2
	Battery clamp screw ~ Winding stem	. 3
	Train wheel bridge screw ~ Main plate	. 4
IV.	CHECKING AND ADJUSTMENT 5 ~	7

#### I. SPECIFICATIONS


Cal. No.	2B21A	
Indication system	3 hands	
Additional mechanism	Electronic reset switch Second setting device	
Loss/gain	Monthly rate: Less than 20 seconds at normal temperature range	
Size of main plate	15.5 mm (6H – 12H) × 13.0 mm (3H – 9H)	
Casing diameter	15.1 mm	
Height	2.4 mm (including battery)	
Quartz Tester measuring gate	10-second gate	
Battery	SEIZAIKEN TR521SW, MAXELL SR521SW, SONY EVEREADY 379 Voltage: 1.55V Battery life: Approx. 2 years	
Jewels	1 jewel	

#### II. STRUCTURE OF CIRCUIT BLOCK




#### III. DISASSEMBLING, REASSEMBLING AND LUBRICATING

Disassembling procedures: Figs  $\textcircled{1} \sim \textcircled{3}$ Lubricating: Reassembling procedures: Figs 33 ~ ① Types of oil Oil quantity ● Hands ~ Hour wheel Small Moebius A Standard > Seiko oil S-6 CC ① Hour, minuite and second hands 2) The dial legs are inserted into the holes in the Dial spacer 29 and Winding stem cock \* To remove the dial, insert a small screwdriver into the notches for dial removal ② Dial of the main plate (2 portions) and lift the dial out. Ф 3 Dial washer 4 Hour wheel ring 4 Hour wheel Notch for dial removal Notch for dial removal (at 2 o'clock position) (at 7 o'clock position) \* Removing/installing winding stem Screwdriver Insert a screwdriver between the Winding stem holder (1) and Winding stem cock (3) and pull out the winding stem while lifting up the winding stem hol-Winding stem holder (1) der. Winding stem cock (6)




#### ● Train wheel bridge screw ~ Main plate


Cross-sectional view of gear train




Plane figure



#### Set position of reset lever





#### IV. CHECKING AND ADJUSTMENT

Procedure for checking and adjustment

- This section only gives the checking and adjustment procedure which is exclusive for this watch.
- For the normal checking and adjustment, refer to the "TECHNICAL GUIDE GENERAL INSTRUCTION, Analogue Quartz"
- The page numbers in the item correspond to those in the "TECHNICAL GUIDE GENERAL INSTRUCTION, Analogue Quartz".


OUTPUT SIGNAL p.6	
<ol> <li>Use the Quartz Tester.</li> <li>Turn the measuring gate selection switch to "10-second" gate.</li> </ol> NOTE:	Result: Output signal: Normal No output signal: Defective
Checking should be made with the crown set to normal position.	
BATTERY VOLTAGE	
Use the Digital Multi Tester S-840A. Range to be used: DC V	Result: 1.57V or more: Normal Less than 1.57V: Defective
<b>NOTE:</b> Before measuring, short circuit the probes and confirm that the tester reads AUTO 00.0 mV or AUTO 00.1 mV.	Replace the battery.
BATTERY CONDUCTIVITY p.9	
Check the conductivity between battery and battery connection (-), etc.	
CIRCUIT BLOCK CONDUCTIVITY p.9	
Check the output terminal and pattern section contamination in the circuit block and check if the circuit is broken or short.	
COIL BLOCK	
Check the coil block for broken wire and short circuit using the Digital Multi Tester S-840A. Range to be used: $arOmega$	Result: 2.9 $\sim$ 3.3 k $\Omega$ : Normal Less than 2.9 k $\Omega$ (Short circuit): Defective
<ul> <li>NOTE:</li> <li>Before measuring, short circuit the probes and check to see if the tester sounds and reads from AUTO 00.2Ω to AUTO 00.4Ω. The actual resistance can be obtained by subtracting the initial value (00.2 – 00.4) from the measured value.</li> <li>When measuring, take care not to break the coil block leads.</li> </ul>	More than 3.3 kΩ (Broken wire):  Defective  Replace the coil block.
FRONT GEAR TRAIN MECHANISM p.11	
Check the front gear train mechanism for play of step rotor and wheels and pinions, mis-installation, dust, lint, foreign matter, lubrication, etc.	
BACK GEAR TRAIN MECHANISM p.11	
Check the back gear train mechanism for lubrication leakage, play, dust, lint, etc.	

#### **RESET CONDITION** With the movement installed, check that the reset condition is normal. 1. Check the clearance between the train wheel setting lever and fourth wheel and pinion. (1) Check the clearance with the crown at normal position. Result: Clearance: Normal Fourth wheel No clearance: Defective Train wheel setting lever and pinion Replace the train wheel setting lever. Clearance O Normal Defective (2) Check the clearance with the crown at first click position. Result: No clearance: Normal Clearance: Defective Replace the train wheel setting lever. Clearance Defective Normal 2. Check, the output signal with the battery installed. (1) Check the output signal with the crown at normal position. Result: Output signal: Normal No output signal: Defective Replace the reset lever. (2) Check the output signal with the crown at first click position. Result: No output signal: Normal Output signal: Defective Replace the reset lever. ACCURACY p.13 Check accuracy using Quartz Tester (10-second gate) and an electro-Monthly rate (at normal temperature magnetic microphone (DM-1). range) NOTE: Less than 20 seconds: Normal More than 20 seconds: Defective Check accuracy with the crown at normal position. Replace the circuit block

#### **CURRENT CONSUMPTION**

Use the Digital Multi Tester S-840A (with Multi Adaptor MA-40).

Mode: μA



Result:

0.9  $\mu$ A or less: Normal More than 0.9  $\mu$ A: Defective Replace the circuit block

#### NOTE:

Press the reset switch to read 00.0  $\mu\text{A}$  and measure the current consumption.

Red probe → Battery connection (+)

Black probe → Battery connection (-)

When measuring the current consumption under the incandescent lamp, cover the movement with black cloth. Otherwise the measured value sometimes becomes higher than the actual value.