

# PARTS CATALOGUE/TECHNICAL GUIDE

## Cal. 6M25A

#### [SPECIFICATIONS]

Cal. No.		CRA9E A			
Item		6M25A			
Movement		The state of the s			
		(x 1.0)			
	Outside diameter	28.5 mm between 6 o'clock and 12 o'clock sides ø27.0 mm between 3 o'clock and 9 o'clock sides			
Movement size	Casing diameter	ø26.4 mm			
	Height	3.9 mm			
Time indication		3 hands and mode indicator			
Driving system		Step motor (4 pcs.)			
Additional mechanism		Alarm function (12-hour indication system)     Countdown timer (Up to 60 minutes)     Stopwatch function (Up to 60 minutes in 1/10 seconds)     Month and date (Automatic calendar)     Hands 0-reset adjustment function     Alarm test system     Demonstration movement of the hands     Electronic circuit reset switch     Battery life indicator			
Loss/gain		Monthly rate at normal temperature range: less than 15 seconds			
Regulation system		Nil			
Measuring gate by quartz tester		Use 10-second gate (in "CHRONO Ø" mode).			
Battery		SEIKO SR927W, Maxell SR927W, SONY SR927W, EVEREADY 399 Battery life is approximately 2 years. Voltage: 1.55V			
Jewels		9 jewels			





#### Remarks:

- (7) Hour wheel
- (40) Fourth wheel and pinion
- (46) Center wheel and pinion
- Discrimination of the installing height of the hands

Cal. 6M25A watches have numerals printed on the dial and movement to indicate the installing heights of hands. When expairing, refer to the table below.

	Height	Standard type	Long type	
Discrimination	Numeral for discrimination	2		
Printed on		Dial Movement		
Printed position		The numeral is printed at	The numeral is printed below	
		the right end.	the calibre number.	

\* The installing heights of the hands can be known from the shape of the following parts. Refer to the table below.

Numeral for discrimination	Center wheel and pinion	Fourth wheel and pinion	Hour wheel
2			
	221 154	241 154	271 438
3			
	221 155	241 155	271 439

## PARTS CATALOGUE

Cal. 6M25A

(10) Date dial

Part code	Position of crown and calendar	Color of figure	Color of background
801 451	3 o'clock	Black	White

The type of date dial is determined based on the design of cases.

Check the case number and refer to "SEIKO CASING PARTS CATALOGUE" to choose a corresponding date dial.

(12) Winding stem 351 168

The type of winding stem is determined based on the design of cases.

Check the case number and refer to "SEIKO CASING PARTS CATALOGUE" to choose a corresponding winding stem.

(18) Switch spring

4245 456 :

Use with the movement having the discrimination numeral "2".

4245 457 :

Use with the movement having the discrimination numeral "3".

· Piezoelectric element

4589 650


## TECHNICAL GUIDE

Cal. 6M25A

• The explanation here is only for the particular points of Cal. 6M25A.


 For the repairing, checking and measuring procedures, refer to the "TECHNICAL GUIDE, GENERAL INSTRUCTIONS".

#### I. STRUCTURE OF THE CIRCUIT BLOCK




#### II. REMARKS ON INSTALLING THE BATTERY


After the battery is replaced with a new one, or after the battery is re-installed following the repairing
procedures, be sure to short-circuit the AC terminal of the circuit block and the battery connection (+) with
conductive tweezers to reset the circuit as shown in the illustration below.
(When checking the current consumption, short-circuit with the power supplied from external source.)



- To reset the circuit of the complete watch, follow the procedure below.
  - (1) Turn the crown to set the mode indicator to "CHRONO Ø".
  - (2) Pull out the crown to the first click.
  - (3) Keep buttons "A" and "B" pressed at the same time for approximately 2 seconds. When the buttons are released, a beep sounds and the hour and minute hands start moving counterclockwise and clockwise, respectively. The second hand moves back and forth.



- (4) Press button "A" or "B" once to stop the hands.
- (5) Press button "A" to select the hand or date to be adjusted in the following order.



- \* The hand selected to be adjusted will move back and forth and return where it was. The date will advance one day and return to the current date if selected.
- (6) Press button "B" to reset the selected hand to the "12" o'clock position and set the date to "1".

  \* The hands and date move quickly if the button "B" is kept pressed for 2 seconds.
- (7) Push the crown back in to the normal position.
- After all the adjustments for resetting the circuit are completed, turn the crown to set the mode indicator
  to "TIME" to set the desired time, turn it to "ALARM SET" to set the alarm, and turn it to "DATE MONTH"
  to set the desired month and date.
  - \*The time can also be set by setting the mode indicator to "ALARM ON".

## **TECHNICAL GUIDE**


Cal. 6M25A

#### III. REMARKS ON DISASSEMBLING AND REASSEMBLING

Use the universal movement holder for disassembling and reassembling.

(1) Hands


Since a plastic main plate is used, place the movement on a flat metal plate or the like, and then install the hands at the 12 o'clock position.



### (2) Mode indicator

#### How to remove

Set a hand-removing jig at the center of the mode indicator to remove it. In doing so, check that the hand-removing jig is set right at the center of the mode indicator. Otherwise, the mode indicator may be deformed.




[Correct]

[Incorrect]

#### How to install

Place the movement on a flat metal plate or the like, and then set the mode indicator and the mode indicator arbor following the procedure below.

(1) Turn the crown to set the notched portion of the mode indicator arbor at the 6 o'clock position.




Set the notched portion at the 6 o'clock position.

(2) Install the mode indicator so that it points to "TIME".




(3) After installing the mode indicator, give it three full turns by turning the crown to check if it stops exactly at the respective mode positions.

If the mode indicator arbor is loose in the contact with the mode indicator's pipe, the mode indicator will stop out of the proper positions. In that case, slightly flatten the mode indicator's pipe at the part indicated in the illustration, and then install the mode indicator to the mode indicator arbor again.



3 Dial

Pry up the dial at the two recessed parts indicated in the illustration using a screwdriver.



- (6) Dial washer
- (47) Center wheel friction spring
- How to distinguish the two parts

[Dial washer]


[Center wheel friction spring]



· With the larger diameter

· With the smaller diameter


Setting position



(9) Intermediate wheel for mode indicator (B)

#### How to install


Set the intermediate wheel for mode indicator (B) to the mode indicator arbor so that it fits in with the notched part of the mode indicator arbor.



### (10) Date dial

#### How to install


Since a plastic date dial is used, make sure that the teeth of the date dial and the date driving wheel securely mesh with each other.



### (12) Winding stem

#### How to remove


Remove the winding stem while pushing the indented portion of the switch spring (marked with "\DVSH").



### (13) Clutch wheel

#### How to install


Be sure to install the clutch wheel in the direction as shown in the illustration.




(18) Switch spring

#### How to install

Set the three hooking portions of the switch spring to the main plate.






Take care not to deform the switch spring when disassembling or reassembling it.

(19) Switch pin

Check that proper clearance is provided between the switch pin and circuit block.



Crown at the normal

position

: Clearance provided.

Crown at the first click: No clearance provided.

(21) Coil block spacer

#### How to install

Two types of coil block spacers are available, and they can be used interchangeably. Take care not to install up side down.




Switch spring side

Main plate side




Install in either direction.



#### How to remove

Catch the protrusion of the printed circuit board and pull it up to remove.






(24) Contact point spring


Setting position



Check if the contacting portion with the circuit block is deformed.



Set the contact point spring to the mode indicator arbor so that it fits in with the notched part of the mode indicator arbor.







Battery connection (-)

• How to instail

Set the battery connection (-) along the guide groove of the main plate.





## **TECHNICAL GUIDE**

#### • Distinction of motors

Distinction Part name	Second motor	Minute motor	Hour motor	Date motor
Step rotor				
Rotor stator	676	676		
	No mark	Marked with "1"	Marked with "2"	Marked with "3"
Coil block	Mold agent: Blue Larger diameter	Mold agent: Green Standard diameter		Mold agent: Red Smaller diameter

### (55) Mode indicator jumper


Take care not to deform the mode indicator jumper when disassembling or reassembling it, as extremely high pressure is applied to it.

#### · How to remove

Release the tip of the mode indicator jumper from the mode indicator arbor, and then lift up "A" portion in the illustration.

#### How to install

Reverse the procedures for disassembling.



#### IV. VALUE CHECKING

#### · Coil block resistance

Coil block for second motor :  $1.5 \text{K}\Omega \sim 1.9 \text{K}\Omega$ Coil block for minute and hour motor :  $1.2 \text{K}\Omega \sim 1.6 \text{K}\Omega$ Coil block for date motor :  $0.8 \text{K}\Omega \sim 1.2 \text{K}\Omega$ 

#### • Upconverter coil resistance

 $120\Omega \sim 180\Omega$ 

#### Measuring time accuracy

[1] Turn the crown to set the mode indicator to "CHRONO  $\emptyset$ ".

- \* When the stopwatch is counting, press button "A" to stop the measurement and then press button "B" to reset the hands.
- [2] Set the gate of the guartz tester to "10" and then put the watch on the microphone.

#### Note:

To measure the time accuracy, be sure to set the watch in the "CHRONO Ø" mode and check that the stopwatch has been reset. A small amount of output signal is constantly generated for the measurement use. If the measurement is made in the "TIME" mode with the hands moving, no stable measurement can be obtained.

#### • Current consumption

For the whole of the movement : less than 3.0µA For the circuit block alone : less than 0.8µA

- [1] Tighten the two battery clamp screw, and install the dial, hands and mode indicator.
- [2] Turn the crown to set the mode indicator to "TIME", and supply the power from the external source.
- [3] Short-circuit the AC terminal of the circuit block and the switch spring twice to reset the circuit.
- [4] Press button "A" or "B" to set the hands moving, and then measure the current consumption.

#### Note:

The motors move the hands and date calendar at the following intervals.

Second motor: 1-second intervals
Minute motor: 10-seconds intervals
Hour motor: 2-minutes intervals
Date motor: 24-hours intervals

### **TECHNICAL GUIDE**

Calculate the current consumption following the formula below.

(Ex.)

1.5 (
$$\mu$$
A) -  $\frac{2.5 (\mu$ A) - 1.5 ( $\mu$ A) = 1.6 ( $\mu$ A)

\* The value of the numerator represents the current consumption of the minute motor, which moves at 10-second intervals. To obtain the current consumption to a second, it should be divided by "10".

#### Note:

To obtain the current consumption of the movement, it is necessary to add up the measured values of all the motors by converting them to the values to a second. However, the hour and minute motors' current consumption to a second is so small that it will not affect the aggregate of the current consumption. Therefore, it is safely assumed that the above formula represents the current consumption of the movement.