
SEIKO



작다 Please see remarks on the next page.

As for all other parts not shown here, please refer to the basic calibre

(Cal. No. **2406 Å** 23J Catalog No. 24-06-1 Red page).

2415A 23i Basic Calibre 2406A 23J Catalog No. 24-06-1 LIST OF MATERIALS PART NO. LIST OF MATERIALS Lower hole lewel for 1st reverser idler 011 157 Barrel & train-wheel bridge 011 157 Upper hole jewel for 1st reduction wheel Center wheel bridge Lower hole jewel for 1st reduction wheel 011 157 Lower hole jewel for barrel 011 159 Balance cock Framework for automatic device 011 212 Diashock upper cap jewel Diashock lower cap jewel Complete barrel with arbor & mainspring 011 212 Upper hole jewel for differential wheel Center wheel & pinion with cannon 011 422 Lower hole lewel for differential wheel 011 422 Upper hole jewel for escape wheel 011 505 Cannon pinion Lower hole jewel for escape wheel 011 505 Third wheel & pinion Fourth wheel & pinion 011 505 Upper hole jewel for pallet Lower hole lewel for pallet 011 505 Escape wheel & pinion 011 521 Upper hole lewel for center wheel Minute wheel Lower hole jewel for center wheel Hour wheel 011 521 011 541 Upper hole jewel for 4th wheel Clutch wheel Lower hole jewel for 4th wheel 011 541 Winding pinion 011 542 Upper hole jewel for 3rd wheel Crown wheel 011 542 Lower hole jewel for 3rd wheel Ratchet wheel 012 123 Stud screw Jewelled pallet fork & staff Balance complete with stud 012 126 Center wheel bridge screw Minute wheel bridge screw 012 126 Balance staff 012 275 Bridge screw Roller with jewel 012 275 Balance cock screw 012 275 Framework screw for automatic device 012 297 Crown wheel screw 012 421 Transmission wheel screw Winding stem 012 762 Dial screw 012 763 Pallet cock screw Joint stem (movement portion) 012764 Casing clamp screw Joint stem (case portion) 012 767 Setting lever spring screw Click spring 012 767 Date driving wheel screw 012 767 Date jumper guard screw 012 767 Screw for setting wheel lever complete Setting lever Tube for screw of setting wheel lever 013 064 complete 013 065 Tube for yoke Yoke (Clutch lever) (Tube for barrel & train-wheel bridge screw) Minute wheel bridge Setting lever spring 013 834 Click pin Second reduction wheel pin Setting lever axle 013 836 Casing clamp 013 837 Date dial guard pin Holding ring for setting wheel lever complete Diashock upper frame 014 413 Diashock lower frame Crown wheel ring 014414 014 415 Diashock hole jewel with frame Hour wheel ring Diashock spring 014 417 Transmission wheel Oscillating weight with ball-bearing First reduction wheel Second reduction wheel Differential wheel Date driving wheel Setting wheel lever complete Date dial guard Date jumper guard Date jumper Intermediate date wheel First reverser idler Second reverser idler Holding ring for dial Date driving wheel holder

Jewels

Style Name

☆⇒ Please see remarks on the next page.

Items in light letters are not shown in photos; those parts are interchangeable with the basic calibre

(Cal. No. 2406A 23J Catalog No. 24-06-1 Red page).

Calibre No.

lewels

23i

Style Name

ED Basic Callbre 2406A 23J Catalog No. 24-06-1

Remarks:

Winding stem — There are three types of winding stems. Select a suitable one by referring to the photographs in the page of the basic calibre and the shapes in the lower diagram.

\$3.54 240 a size is 1.26 mm and thread is provided completely on the crown portion. \$354 241 a size is 3.80 mm and thread is provided only on the end of the crown portion.

\$354 242 a size is 1.26 mm and thread is provided only on the end of the crown portion.



☆354 240

☆354 241

☆354 242


Setting lever

There are four types of setting levers. They are used according to the shapes of dial, structures of case and types of winding stem. Select a suitable one by the following procedures referring to the shapes indicated in Fig. 1.

☆383 240 ····· Used for watch with joint stem, or with ordinary winding stem other than one-piece or square-type water-resistant case.


☆383 241) Those setting levers are used for ☆383 242 }··· one-piece or square-type water - re-☆383 243 sistant case with ordinary winding stem. Select the setting lever whose tail can be set between the dial and the case as shown Fig. 2 when assembling the movement in the case by referring to the shapes in Fig. 1. If an in incorrect setting lever for dial diameter is used, the winding stem can not be pulled out or the movement can not be set in the case. Attention must be paid to this point.

When part number of the setting lever is unknown, specify ① Cal. No. ② jewels ③ dial No. and ④ case No.



☆383 242 ☆383 243 ☆383 240 ☆383 241

(Fig. 2)



(Example of suitable setting lever) Tail of the setting lever is located between the dial and the case.

Date dial

\$801 242 Used when both the crown and the date frame are located at 3 o'clock position. \$801 245 Used when the crown is located at 3 o'clock position and the date frame at 6 o'clock position.

If the date dial is required in any other type, specify ① Cal. No. ② jewels ③ the crown position

① the date frame position and ⑤ dial No.


Holding ring for dial — The holding ring for dial differs according to the design of the dial. Select the suitable one by the following procedures.

 $$884\ 242 \cdots$ Refer to the photograph on the front page and Fig. 1.

When ordering the other part than the above, specify the part number printed in the 12 o'clock direction of the dial (Refer to Fig. 2).

If the part number of the holding ring for dial is unknown, specify ① Cal. No. ② jewels ③ dial No. and (1) case No.







The part number of the holding ring for dial to be used for this dial.

☆884 242